

































































































Original		Sustituto		Original		Sustituto	
	Power		Power		CH-		Ch -
	1		1		Info		Info
	2		2		EPG		Guide
	3		3		Up		Up
	4		4		Left		Left
	5		5		Right		Right
	6		6		Down		Down
	7		7		Exit		Exit
	8		8		Yellow / Pause		Yellow
	9		9		Blue / >>		Blue
	0		0		@ / Stop		Smart
	Radio / AV		TV/R		@ / Stop		Stop
	Lang / -/--		Dual		Rec / [ ]		Rec
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				
	CH+		Ch +				





Original	Sustituto	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
App		Media
Info		Info
TV		TV/R
Text		Text
Menu		Menu
Menu Up		Up
Display	 + 	Shift + Info
Menu Left		Left
OK Enter		Ok
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Volume+		Vol +

Original	Sustituto	
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7
8tuv		8
9wxyz		9
Guide Pilote		Guide
0/10		0
FAV Pref.		Pre Ch
Red		Red
Green		Green



