




























Original	Sustituto
Power	Power
Mute	Mute
More	Smart
Code	Media
Code	+ Shift + Media
Sleep	Sleep
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Zoom	Eject

Original	Sustituto
OPT	Options
Red / <<	Red
Green / Stop	Green
Yellow /	Yellow
Blue / >>	Blue
Red / <<	<<
Green / Stop	Stop
Yellow /	Play
Yellow /	Pause
Blue / <<	>>
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
TV/Radio	TV/R
Rec	Rec









































Original		Sustituto		Original		Sustituto	
	Back		Back				
	Info		Info				
	Prog-		Ch -				
	Prog+		Ch +				
	Vol-		Vol -				
	Vol+		Vol +				
	TXT		Text				
	Still	 + 	Shift + Pause				
	Sound		Dual				
	PIP		Format				
	Menu		Menu				
	HDMI		AV				





Original	Sustituto	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Opt?		Options
Subt.List		Subt
App		Media
Info	 + 	Shift + Info
Sleep Timer		Sleep
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left

Original	Sustituto	
OK Enter		Ok
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7






















Original	Sustituto	Original	Sustituto
8tuv	8	Lang./Rewind	<<
9wxyz	9	LNB F.Forward	>>
Guide Pilote	Guide		
0/10	0		
FAV Pref.	Pre Ch		
Red	Red		
Green	Green		
Dev	List		
Home Cinema	Smart		
West	I<<		
Yellow	Yellow		
Freeze	Stop		
Blue	Blue		
On/Off	+ Shift + Power		
SAT Sky	+ Shift + AV		
H/V Play	Play		
East	>>I		




























Original	Sustituto	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Sleep Timer		Sleep
Opt?		Options
App		Media
Info	 + 	Shift + Info
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left
OK Enter		Ok

Original	Sustituto	
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7
8tuv		8





Original	Sustituto	Sustituto
9wxyz		9
Guide Pilote		Guide
0/10		0
FAV Pref.		Pre Ch
Freeze		Stop
Scan/Setup	 + 	Shift + Options
Red		Red
Auth./DISEQC		List
Green		Green
Radio	 + 	Shift + TV/R
Yellow		Yellow
Blue		Blue
Home Cinema		Smart
Alt/16:9		Format
SAT Sky	 + 	Shift + AV
Dec/Pause		Pause
	 + 	Shift + Exit

Original	Sustituto	Sustituto
East		>>
Lang./Rewind		<<
H/V Play		Play
LNB F.Forward		>>

