







































































| Original | Sustituto | Original | Sustituto |
|---|--|---|---|
|  Standby |  Power |  Up / Channel+ |  Ch + |
|  1 |  1 |  Down / |  Down |
|  2 |  2 |  Down / |  Ch - |
|  3 |  3 |  Right |  Right |
|  4 |  4 |  Left |  Left |
|  5 |  5 |  Select |  Ok |
|  6 |  6 |  Mute |  Mute |
|  7 |  7 |  Vol+ |  Vol + |
|  8 |  8 |  Vol- |  Vol - |
|  9 |  9 |  Menu |  Menu |
|  0 |  0 |  A/V |  AV |
|  SAT / Recall |  Smart |  Tune |  Media |
|  SAT / Recall |  Back |  Text |  Text |
|  Favorite |  Pre Ch |  Subtitle |  Subt |
|  View |  Info |  Store |  Options |
|  Cancel |  Exit |  Reveal |  3D |
|  Up / Channel+ |  Up |  Aspect |  Format |

