













































Original	Sustituto
	 Power
	 Mute
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Info
	 Guide
	 Vol +
	 Vol -
	 Menu

Original	Sustituto
	 Text
	 Ch +
	 Ch -
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Exit
	 Options
	 Red
	 Green
	 Yellow
	 Blue
	 Format
	 Media
	 Smart



