



Original	Sustituto
A-B	A-B
MUTE	MUTE
DVD/DVB	DVD/DVB
SOURCE	SOURCE
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
10+	10+
DISPLAY	DISPLAY
SUBTITLE	SUBTITLE

Original	Sustituto
ANGLE	ANGLE
AUDIO	AUDIO
MENU	MENU
TITLE / TV/RADIO	TITLE / TV/RADIO
RETURN	RETURN
SEARCH	SEARCH
SLOW	Slow
UP	UP
LEFT	LEFT
ENTER	ENTER
RIGHT	RIGHT
DOWN	DOWN
SETUP	SETUP
VOL-	VOL-
VOL+	VOL+
PLAY	PLAY
PAUSE	PAUSE



