



Original	Sustituto
	Zoom / Size
	Power
	TV/Radio /
	Guide / EPG / -/--
	Info / Angle
	Picture / Format
	AV / Input / RDS
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Smart / List

Original	Sustituto
	0
	Display / Media
	Setup / OPT /
	Up
	Menu / Home
	Left
	OK
	Right
	Back / Return
	Down
	Exit / Cancel / Clear
	Vol+
	Fav / Marker / PC
	CH+ / Page+
	Vol-
	Audio / Lang I/II
	CH- / Page-



