



Original	Sustituto	Original	Sustituto
	On/off		Power
	Sleep		Sleep / Timer
	CD		Shift + 3
	Ipod		2
	FM		3
	USB		8
	< Preset		Shift + I<< / Preset-
	> Preset		Shift + >>I / Preset+
	<< Tuning		<< / Tune-
	>> Tuning		>> / Tune+
	Memory		Smart / List
	Clock/Set		D.Menu / Top
	Function		Setup / OPT /
	Display		Display / Media
	Menu		Menu / Home
	Play/Pause		Play / Slow
	>>I		>>I / Preset+
	I<<		I<< / Preset-
	Ok		OK
	Up		Up
	Down		Down
	Folder Up		CH+ / Page+
	Folder Down		CH- / Page-
	Stop		Stop / Hold
	DSP		Guide / EPG / -/-
	Random		Blue / Prime Video / Random
	Repeat		Green / APP / Repeat
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer

