



Original	Sustituto
	Zoom / Size
	Power
	AV / Input / RDS
	>> / Tune+
	Red / Netflix / Search
	Green / APP / Repeat
	<< / Tune-
	Yellow / YouTube / Repeat
	Stop / Hold
	Blue / Prime Video / Random
	Play / Slow
	TV/Radio /
	Text / Goto
	D.Menu / Top
	Menu / Home
	Up
	Down

Original	Sustituto
	Left
	Right
	Vol+
	Vol-
	Mute / Dimmer
	CH+ / Page+
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0





Original		Sustituto		Original		Sustituto	
	[i+]		Info / Angle				
	I-II		Audio / Lang I/II				
	[112]		Subtitle / EQ				
	[:≡]		Guide / EPG / -/--				
	[<>]		Picture / Format				
	P<P		Fav / Marker / PC				
	♪/Smart		Smart / List				
	[]/Smart		Display / Media				





Original	Sustituto
Power SAT	+ Shift + Power
Power	Power
Source/[?]	AV / Input / RDS
Source SAT	+ Shift + AV / Input / RDS
>>	>> / Tune+
Red SAT	Red / Netflix / Search
<<	<< / Tune-
Green SAT	Green / APP / Repeat
Yellow SAT	Yellow / YouTube / Repeat
Stop	Stop / Hold
Play	Play / Slow
Blue SAT	Blue / Prime Video / Random
Radio	TV/Radio /
[=]	Text / Goto
Up	Up
Up SAT	+ Shift + Up
Down	Down

Original	Sustituto
Down SAT	+ Shift + Down
Left SAT	+ Shift + Left
Left	Left
Right SAT	+ Shift + Right
Right	Right
OK SAT	+ Shift + OK
OK	OK
[] SAT	+ Shift + Back / Return
[]	Back / Return
Menu SAT	D.Menu / Top
Menu	Menu / Home
Vol+	Vol+
Vol-	Vol-
Mute	Mute / Dimmer
P+ SAT	+ Shift + CH+ /
P+	CH+ / Page+
P- SAT	+ Shift + CH- /

Page-































Original	Sustituto
P-	CH- / Page-
1 SAT	+ 1 Shift + 1
1	1 1
2 SAT	+ 2 Shift + 2
2	2 2
3 SAT	+ 3 Shift + 3
3	3 3
4 SAT	+ 4 Shift + 4
4	4 4
5 SAT	+ 5 Shift + 5
5	5 5
6 SAT	+ 6 Shift + 6
6	6 6
7 SAT	+ 7 Shift + 7
7	7 7
8 SAT	+ 8 Shift + 8
8	8 8

Original	Sustituto
9 SAT	+ 9 Shift + 9
9	9 9
0 SAT	+ 0 Shift + 0
0	0 0
[i+]	INFO Info / Angle
I-II	AUDIO Audio / Lang I/II
[<>]	PICTURE Picture / Format
P<P	PC FAV MARKER Fav / Marker / PC





Original	Sustituto
 Power	 Power
 >>	 >> / Tune+
 <<	 << / Tune-
 Stop	 Stop / Hold
 Play	 Play / Slow
 Radio	 TV/Radio /
 []	 Back / Return
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 P-	 CH- / Page-
 1	 1

Original	Sustituto
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [i+]	 Info / Angle
 I-II	 Audio / Lang I/II





Original	Sustituto
Power AMP	Shift + Power
Power	Power
Source/[?]	AV / Input / RDS
>>	>> / Tune+
>> AMP	>>I / Preset+
Red	Red / Netflix / Search
Rec	Rec / Rec Mode
<< AMP	I<< / Preset-
Green	Green / APP / Repeat
<<	<< / Tune-
Yellow	Yellow / YouTube / Repeat
Stop	Stop / Hold
Blue	Blue / Prime Video / Random
Play	Play / Slow
Radio AMP	TV/Radio /
[=] AMP	Text / Goto
[]	Back / Return

Original	Sustituto
Menu	Menu / Home
Menu AMP	D.Menu / Top
Up AMP	Shift + Up
Up	Up
Down	Down
Down AMP	Shift + Down
Left	Left
Left AMP	Shift + Left
Right	Right
Right AMP	Shift + Right
OK	OK
OK AMP	Shift + OK
Vol+ AMP	Shift + Smart / List
Vol+	Vol+
Vol-	Vol-
Mute AMP	Shift + Mute / Dimmer
Mute	Mute / Dimmer





Original	Sustituto

Original	Sustituto

