



Original	Sustituto
POWER	Power
SLEEP	Sleep / Timer
6 CH. INPUT	AV / Input / RDS
DVD	Shift + 2
D-TV / CBL	2
VCR	4
V-AUX	7
CD	3
TUNER	6
MD / CD-R	9
TUNER - PRESET-	CH- / Page-
TUNER - PRESET+	CH+ / Page+
TUNER - A	Red / Netflix / Search
TUNER - B	Green / APP / Repeat
TUNER - C	Yellow / YouTube / Repeat
TUNER - D	Blue / Prime Video / Random
TUNER - E	Setup / OPT /

Original	Sustituto
HALL	0
JAZZ CLUB	1
ROCK CONCERT	Sound / Title
ENTERTAINMEN	Smart / List
TV SPORTS	Shift + 1
MONO / MOVIE	Picture / Format
MOVIE THEATER - 1	5
MOVIE THEATER - 2	8
DOLBY / DST SUR.	Eject / Surround
MATRIX 6.1	Guide / EPG / -/--
SELECT	OK
LEVEL	Display / Media
UP	Up
SET MENU	Menu / Home
-	Left
+	Right
TEST	Text / Goto



