



Original	Sustituto	Original	Sustituto
 Power	 Power		
 Mute	 Mute / Dimmer		
 HDMI ARC	 0		
 Optical	 Setup / OPT /		
 +	 Vol+		
 I<	 I<< / Preset-		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 >I	 >>I / Preset+		
 -	 Vol-		
 BT	 9		
 Voice	 Smart / List		
 News	 Info / Angle		
 Music	 Audio / Lang I/II		
 Movie	 Picture / Format		

