



Original	Sustituto
	Power
	Ambilight
	Info
	Search
	Sources
	Up
	Left
	OK
	Right
	Down
	Back / Return
	Home
	Menu / Home
	<< / Tune-
	Play / Slow
	>> / Tune+
	Stop / Hold

Original	Sustituto
	Pause / Step / Freeze
	Rec / Rec Mode
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Vol+
	Shift + Red / Netflix /
	CH+ / Page+
	Mute / Dimmer
	Smart / List
	Exit / Cancel / Clear
	Vol-
	TV/Radio /
	CH- / Page-
	1
	2





Original	Sustituto	Original	Sustituto
3	3	CO - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TEXT	Text	GOTO TEXT	Text / Goto
0	0	HDMI - BAT 0	0
LIST TV GUIDE	List/Tv Guide	GUIDE EPG	Guide / EPG / -/--

Original	Sustituto

