


























| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  Source |  AV |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  I/II/Audio |  Dual |
|  Sleep |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0/10 |  0 |

| Original | Sustituto |
|---|---|
|  List/+10 |  Guide |
|  Recall/Program |  Back |
|  Tv Menu |  Menu |
|  Exit |  Exit |
|  Goto/Text |  Text |
|  Info/Display |  Info |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK/Enter |  Ok |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Red/DVD Setup |  Red |
|  Green/A-B |  Green |





| Original | | Sustituto | | Original | Sustituto |
|---|--------------|---|---------------|----------|-----------|
|  | Yellow/Angle |  | Yellow | | |
|  | Blue/Repeat |  | Blue | | |
|  | Subtitle |  | Subt | | |
|  | Play/Hold |  | Play | | |
|  | Pause |  | Pause | | |
|  | Size |  | Format | | |
|  | D.Dis/Reveal |  | 3D | | |
|  | D.Menu/Mix |  | D. Menu | | |
|  | Zoom/Index |  | Shift + Eject | | |
|  | I<</FAV |  | I<< | | |
|  | >>I/Subpage |  | >>I | | |
|  | Stop |  | Stop | | |
|  | Tv/Radio |  | TV/R | | |
|  | << |  | << | | |
|  | >> |  | >> | | |
|  | Eject/EPG |  | Eject | | |

