





Original	Sustituto
 Power	 Power
 Picture	 Shift + Format
 Sound	 Shift + Dual
 Input	 AV
 Menu	 Menu
 Exit	 Exit
 16:9/4:3	 Format
 Info	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Sustituto
 0	 0
 FAV	 Pre Ch
 Recall	 Back
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Subtitle	 Subt
 Audio	 Dual
 Goto	 Guide
 Repeat	 Shift + Text





Original	Sustituto	Original	Sustituto
 CH/List	 List		 Blue
 Size	 Eject		
 Sleep	 Sleep		
 ECO/TFT Off	 3D		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		
 Tv/TXT	 Text		
 Subpage	 Options		
 Hold	 TV/R		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		

Original	Sustituto
	 Blue

