



















































Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Source	 AV / Input / RDS
 0	 0
 Info	 Info / Angle
 DMP	 D.Menu / Top
 Up	 Up
 EPG	 Guide / EPG / -/--

Original	Sustituto
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Vol +	 Vol+
 List	 Smart / List
 CH +	 CH+ / Page+
 Vol -	 Vol-
 CH -	 CH- / Page-
 Fav	 Fav / Marker / PC
 Sleep	 Sleep / Timer
 Index	 Display / Media
 Recall	 Back / Return
 Red / <<	 Red / Netflix / Search
 Red / <<	 << / Tune-






















Original	Sustituto
 Green / >>	 >> / Tune+
 Green / >>	 Green / APP / Repeat
 Yellow / I<<	 I<< / Preset-
 Yellow / I<<	 Yellow / YouTube / Repeat
 Blue / >>I	 Blue / Prime Video / Random
 Blue / >>I	 >>I / Preset+
 Text / Play/Pause	 Text / Goto
 Text / Play/Pause	 Pause / Step / Freeze
 Text / Play/Pause	 Play / Slow
 Stop / Still	 Stop / Hold
 Timer / Subtitle	 Subtitle / EQ
 Size / Aspect	 Zoom / Size
 Cancel [≡X]	 +  Shift + Exit / Cancel / Clear
 Radio	 TV/Radio /
 Audio / I/II	 Audio / Lang I/II
 Rec	 Rec / Rec Mode

Original	Sustituto





Original	Sustituto
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	[≡?]/Source
	0
	[≡i]/Info
	DMP
	Up
	EPG

Original	Sustituto
	Left
	Enter
	Right
	Menu
	Down
	Exit
	Vol+
	List
	CH+
	Vol-
	CH-
	Fav / Marker / PC
	Sleep
	Index
	Back
	Red
	<<





Original	Sustituto
	Green / APP / Repeat
	>> / Tune+
	Yellow / YouTube / Repeat
	I<< / Preset-
	Blue / Prime Video / Random
	>>I / Preset+
	Play / Slow
	Pause / Step / Freeze
	Text / Goto
	Stop / Hold
	Picture / Format
	Subtitle / EQ
	Zoom / Size
	Setup / OPT /
	TV/Radio /
	Audio / Lang I/II
	Rec / Rec Mode

Original	Sustituto

