




































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Text	 Text
 Mute	 Mute	 FAV	 Pre Ch
 TV/SAT	 AV	 P-	 Ch -
 SAT	 Smart	 P+	 Ch +
 TV	 Media	 Info	 Info
 Radio	 TV/R	 Up	 Up
 Recall	 Back	 Left	 Left
 1	 1	 OK	 Ok
 2	 2	 OK	 Shift + Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Menu	 Menu
 6	 6	 Exit	 Exit
 7	 7	 Red / Lang	 Red
 8	 8	 Red / Lang	 Dual
 9	 9	 Green / Pause	 Green
 0	 0	 Green / Pause	 Pause





Original		Sustituto		Original		Sustituto	
	Yellow / Sound		Yellow				
	Yellow / Sound	+	Shift + Dual				
	Blue / EPG		Blue				
	Blue / EPG		Guide				

