



Original	Sustituto
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu	Menu
Exit	Exit
Up / Ch+	Ch +
Up / Ch+	Up
Down / Ch-	Ch -

Original	Sustituto
Down / Ch-	Down
Right / Vol+	Vol +
Right / Vol+	Right
Left / Vol-	Vol -
Left / Vol-	Left
Ok/Store	Ok
Info	Info
Tv/Rad	TV/R
Fav	Pre Ch
Epg	Guide
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Subtitle	Subt
Audio	Dual
View	Format



