






































































Original	Sustituto	Original	Sustituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Guide		Guide
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	>>I		>>I
	I<<		I<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/List		Ok
	Menu		Menu
	Back		Back
	Red/Text		Red
	Green/Audio		Green
	Yellow/Sub		Yellow
	Blue/Find		Blue
	<<		<<
	Play		Play
	Pause		Pause





Original	Sustituto
>>	>>
Stop	Stop
Rec	Rec
PVR	Smart
FAV	Pre Ch
[+] / Ratio	3D
Page Up	Shift + Up
Page Down	Shift + Down
[v] / Edit	Media
F1 / Tv / Radio	TV / R
F2 / Input	AV
F3	Subt
F4	Options

Original	Sustituto

