











Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv/Radio	 TV/Radio /
 Video	 Shift + 4
 i	 Info / Angle
 L/R	 Picture / Format
 Play/Pause	 Play / Slow

Original	Sustituto
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Vol+	 Vol+
 OK	 OK
 Vol-	 Vol-
 CH+	 CH+ / Page+
 Green	 Green / APP / Repeat
 Audio	 Audio / Lang I/II
 CH-	 CH- / Page-
 Blue	 Blue / Prime Video / Random
 TTX	 Text / Goto
 Red	 Red / Netflix / Search
 EPG	 Guide / EPG / -/-





Original	Sustituto
 FAV	 Fav / Marker / PC
 Yellow	 Yellow / YouTube / Repeat
	 Subtitle / EQ

Original	Sustituto

