





































Original	Sustituto
 Power	 Power
 Source	 AV
 TV	 TV/R
 VIDEO	 Smart
 PC	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 i	 Info
 List	 List

Original	Sustituto
 ZAP	 Pre Ch
 Format	 Format
 Mute	 Mute
 PIP	 3D
 Text	 Text
 Up / P+	 Up
 Up / P+	 Ch +
 Down / P-	 Down
 Down / P-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 Menu	 Menu
 PIP Swap	 Back
 Auto	 Options
 Sound	 Dual





Original	Sustituto
Freeze / Hold	+ Shift + Stop
<<	<<
Play	Play
>>	>>
Rec	Rec
Stop	Stop
Pause	Pause
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
F1	+ Shift + 1
F2	+ Shift + 2
F3	+ Shift + 3
F4	+ Shift + 4
P-Pos	+ Shift + Ch +
P-Size	+ Shift + Ch -

Original	Sustituto
Clock / Mix	+ Shift + Text

