





































| Original | Sustituto |
|---|---|
|  | Mute / Dimmer  |
|  | Power  |
|  | 1  |
|  | 2  |
|  | 3  |
|  | 4  |
|  | 5  |
|  | 6  |
|  | 7  |
|  | 8  |
|  | 9  |
|  | i / EPG  |
|  | i / EPG  |
|  | 0  |
|  | List  |
|  | CH+ / Page+  |
|  | Up  |

| Original | Sustituto |
|---|---|
|  | Left  |
|  | Vol-  |
|  | OK  |
|  | Vol+  |
|  | Right  |
|  | Down  |
|  | CH- / Page-  |
|  | Exit / Cancel / Clear  |
|  | Menu / Home  |
|  | Rec / Rec Mode  |
|  | Back / Return  |
|  | Red / Netflix / Search  |
|  | << / Tune-  |
|  | Play / Slow  |
|  | Green / APP / Repeat  |
|  | >> / Tune+  |
|  | Blue / Prime Video / Random  |



