




































































| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Eject/Auto |  Eject |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  SHIFT + -/-- Guide |
|  Recall |  FAV PRE-CH Pre Ch |
|  Vol+ |  + VOL Vol + |
|  Vol- |  - VOL Vol - |

| Original | Sustituto |
|---|---|
|  Aspect |  PICTURE FORMAT Format |
|  Audio |  SOUND DUAL Dual |
|  CH+ CH |  + CH Ch + |
|  CH- CH |  - CH Ch - |
|  Display |  DISPLAY INFO Info |
|  Up |  Up |
|  Right |  Right |
|  Down |  Down |
|  Left |  Left |
|  OK |  OK Ok |
|  LCD MENU LCD Menu |  TOP MENU MENU Menu |
|  DVD SETUP EXIT DVD Setup/Exit |  CLEAR EXIT Exit |
|  DVD SETUP EXIT DVD Setup/Exit |  SETTINGS OPT Options |
|  INPUT |  TIMER AV AV |
|  P.Mode |  SHIFT + PICTURE FORMAT Shift + Format |
|  S.Mode |  SHIFT + SOUND DUAL Shift + Dual |
|  SLEEP |  PROG SLEEP Sleep |





| Original | Sustituto |
|---------------|----------------|
| FAV | Shift + Pre Ch |
| FAV- | Shift + Ch - |
| FAV+ | Shift + Ch + |
| EPG | Guide |
| Angle/Text | Text |
| Zoom/Hold | Shift + Eject |
| Tv/Radio | TV/R |
| Goto/Subpage | 3D |
| D.Disp/Reveal | List |
| Subtitle | Subt |
| Title/Size | Smart |
| D.Menu/Index | D. Menu |
| I>/Media | Media |
| Play/Pause | Play |
| << | << |
| Play/Pause | Pause |
| >> | >> |

| Original | Sustituto |
|---------------|-----------|
| Rec | Rec |
| Stop | Stop |
| I<< | I<< |
| >>I | >>I |
| Red/Prog | Red |
| Green/Intro | Green |
| Yellow/Repeat | Yellow |
| Blue/A-B | Blue |

