





































Original	Sustituto
 Power	 Power
 Open/Close	 Eject
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Clear	 Shift + Exit
 Camera	 Options
 Menu	 Menu

Original	Sustituto
 Title	 Guide
 Exit	 Exit
 <<	 <<
 >>	 >>
 Zoom	 Shift + Eject
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 >>	 >>
 <<	 <<
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 Fav	 Pre Ch

