













































Original	Sustituto	Original	Sustituto
	Standby		Power
	Auto		Smart
	Tv/Radio		TV/R
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Back		Back
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Nicam/A2		Options
	Aspect		3D
	Display		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu
	Exit		Exit
	Source		AV
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Sleep		Sleep





Original	Sustituto
Fav	Pre Ch
Fav-	Shift + Ch -
Fav+	Shift + Ch +
Hold	Shift + AV
EPG	Guide
Text	Text
Lang	Dual
Subtitle	Subt
Index	List
Reveal	Eject
Subpage	D. Menu
Media	Media
Size	Format
Play	Play
Pause	Pause
<<	<<
>>	>>

Original	Sustituto
Rec	Rec
Stop	Stop
I<<	I<<
>>I	>>I
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue

