



Original	Sustituto
	Smart
	Media
	TV/R
	AV
	Power
	Eject
	Info
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0

Original	Sustituto
	Shift + AV
	Pre Ch
	I<<
	Rec
	Sleep
	>>I
	<<
	Stop
	Play
	Pause
	>>
	Vol +
	Vol -
	Dual
	Ch +
	Ch -
	Menu



