



































Original	Sustituto
 Power	 Power
 3D	 3D
 TV / RAD	 TV/R
 Guide	 Guide
 Info	 Info
 Q.Menu / Subtitle	 D. Menu
 Q.Menu / Subtitle	 Subt
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
9	9

Original	Sustituto
 0	 0
 List	 List
 Q.View	 Eject
 Home	 Menu
 My Apps	 Smart
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Back	 Back
 Exit	 Exit
 Vol +	 Vol +
 Vol -	 Vol -
 P + / Page +	 Ch +
 P - / Page -	 Ch -
FAV	Pre Ch





Original	Sustituto	Original	Sustituto
	APP / *		Media
	Mute		Mute
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Stop / Live TV		Stop
	Play		Play
	Pause		Pause
	Rec		Rec
	<<		<<
	>>		>>
	Text		Text
	T.Opt		Options

