



| Original | Sustituto | Original | Sustituto |
|--|---|--|---|
|  Power |  Power |  Browser |  Media |
|  Open / Close |  Eject |  Source |  AV |
|  Display |  Info |  Up |  Up |
|  Setup |  Options |  Left |  Left |
|  1 |  1 |  Navi. |  List |
|  2 |  2 |  Enter |  Ok |
|  3 |  3 |  Right |  Right |
|  4 |  4 |  Down |  Down |
|  5 |  5 |  Top Menu |  D. Menu |
|  6 |  6 |  Menu |  Menu |
|  7 |  7 |  Stop |  Stop |
|  8 |  8 |  Play |  Play |
|  9 |  9 |  II> |  Pause |
|  0 |  0 |  I<< |  I<< |
|  CH+ |  Ch + |  >>I |  >>I |
|  CH- |  Ch - |  << |  << |
|  Guider |  Guide |  >> |  >> |



