



| Original | Sustituto |
|--------------|---------------|
| Power | Power |
| Mute | Mute |
| Up / CH+ | Up |
| Up / CH+ | Ch + |
| Left / Vol- | Left |
| Left / Vol- | Vol - |
| Right / Vol+ | Right |
| Right / Vol+ | Vol + |
| Down / CH- | Ch - |
| Down / CH- | Down |
| Enter | Ok |
| Menu | Menu |
| Red / P.M | Red |
| Red / P.M | Format |
| Green / S.M | Green |
| Green / S.M | Shift + Dual |
| Yellow / FAV | Yellow |

| Original | Sustituto |
|--------------|-----------|
| Yellow / FAV | Pre Ch |
| Blue / SLP | Blue |
| Zoom | Eject |
| Freeze | Pause |
| Blue / SLP | Sleep |
| DSP / CAPS | Info |
| Recall | Back |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |





| Original | Sustituto |
|---|---|
|  |  Guide |
|  |  AV |
|  |  Smart |
|  |  Media |
|  |  Shift + Smart |
|  |  TV/R |
|  |  Shift + TV/R |
|  |  Shift + AV |
|  |  Dual |
|  |  Exit |
|  |  Text |
|  |  Shift + Text |
|  |  Stop |
|  |  Options |
|  |  Subt |
|  |  Shift + Eject |

| Original | Sustituto |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

