
































| Original | Sustituto |
|---|---|
|  Aper / Chiuso |  Eject / Surround |
|  Video / Y |  AV / Input / RDS |
|  Power |  Power |
|  OSD |  Display / Media |
|  PBC |  D.Menu / Top |
|  Titolo |  Sound / Title |
|  Menu |  Menu / Home |
|  Ricerca |  Red / Netflix / Search |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  Repeticione |  Green / APP / Repeat |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  A-B RPT |  Yellow / YouTube / Repeat |
|  7 |  7 |

| Original | Sustituto |
|---|---|
|  8 |  8 |
|  9 |  9 |
|  Prog |  TV/Radio / |
|  Intro |  Smart / List |
|  0 |  0 |
|  10+ |  Guide / EPG / -/- |
|  Pausa |  Pause / Step / Freeze |
|  Info / Play |  Play / Slow |
|  Info / Play |  Info / Angle |
|  Up |  Up |
|  Left |  Left |
|  Setup |  Setup / OPT / |
|  Right |  Right |
|  Ritorno |  Back / Return |
|  Down |  Down |
|  Stop |  Stop / Hold |
|  <I Ralent |  CH- / Page- |





| Original | Sustituto | Original | Sustituto |
|----------------|---------------|-------------------------|------------------------|
| [Fast Forward] | Ralent > | [+ CH PAGE] | CH+ / Page+ |
| [REV] | << F.REV | [TUNE-] | << / Tune- |
| [FWD] | >> F.FWD | [TUNE+] | >> / Tune+ |
| [STEP] | Step | [SHIFT] + [STEP-FREEZE] | Shift + Pause / Step / |
| [ZOOM] | Zoom | [SIZE ZOOM] | Zoom / Size |
| [PREC] | << Prec | [PRESET-] | << / Preset- |
| [SUCC] | >> Succ | [PRESET+] | >> / Preset+ |
| [SUBTITOLI] | Sottotitoli | [EQ SUBTITLE] | Subtitle / EQ |
| [NTSC/PAL] | NTSC/PAL | [FORMAT PICTURE] | Picture / Format |
| [VOL-] | Volume- | [VOL -] | Vol- |
| [VOL+] | Volume+ | [VOL +] | Vol+ |
| [AVVOLONE] | Sleep / Timer | [TIMER SLEEP] | Sleep / Timer |
| [TRACK] | Track | [GOTO TEXT] | Text / Goto |
| [AUDIO] | Audio | [LANG I/II AUDIO] | Audio / Lang I/II |
| [MUTO] | Muto | [DIMMER MUTE] | Mute / Dimmer |
| | | | |
| | | | |

| Original | Sustituto |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

