



Original	Sustituto
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Source/[≡]	AV
Normal/OK/[≡i]	Ok
PR+	Ch +
Up	Up
Down	Down
PR-	Ch -

Original	Sustituto
Right/[≡o]	Right
Vol+	Vol +
Vol-	Vol -
Left/[≡+]	Left
Menu	Menu
Mute	Mute
Recall/[≡?]	Pre Ch
Sleep/[≡◇]	Sleep
Red/Skip	Red
Green/Movie	Green
Yellow/Delete	Yellow
Blue/Mode	Blue
[≡]	Text
[≡x]	TV/R

