



































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	P.Mode		3D
	S.Mode		Shift + Dual
	P.Size		Format
	Audio		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Sleep		Sleep
	Recall		Back
	DTV/Radio		TV/R
	Guide		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	FAV.CH		Pre Ch
	Info		Info
	Source		AV
	Menu		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok





Original		Sustituto		Original		Sustituto	
	TS		Media		<<		<<
	Vol+		Vol +		>>		>>
	Vol-		Vol -				
	[≡ ]		List				
	CH+		Ch +				
	CH-		Ch -				
	Text		Text				
	[≡?]		Options				
	Subtitle		Subt				
	[≡◆]		Eject				
	[≡+]		Smart				
	Play		Play				
	Pause		Pause				
	Rec		Rec				
	<<		<<				
	>>		>>				
	Stop		Stop				

