

































































Original	Sustituto	Original	Sustituto
 Standby/On	 Power	 6	 6
 Vol+	 Vol +	 7	 7
 Vol-	 Vol -	 8	 8
 Mute	 Mute	 9	 9
 Band/Tuner	 Media	 0	 0
 CD	 Smart	 +10	 Guide
 P+	 Ch +	 Program	 Sleep
 P-	 Ch -	 Play	 Play
 EQ/X-Bass	 Dual	 Pause	 Pause
 Disp.Demo	 Info	 Stop	 Stop
 I<< Search/Skip/Tunin	 I<<	 Clock/Sleep	 Pre Ch
 Search/Skip/Tunin g/Alb. >>I	 >>I	 Stereo/Beat Cut	 Subt
 1	 1	 Files Search	 TV/R
 2	 2	 Timer	 AV
 3	 3		
 4	 4		
 5	 5		

