



Original	Sustituto	Original	Sustituto
Power	Power	Index Search	OK
Play	Play / Slow	Sharpness/V.Hold	Right
Pause	Pause / Step / Freeze	PGM	Exit / Cancel / Clear
Stop/Eject	Stop / Hold	Index-	Down
Rec	Rec / Rec Mode	Enter/CH.Memo	Back / Return
<<	<< / Tune-	+/MFT+	Vol+
>>	>> / Tune+	Tv Line	Smart / List
I>/Slow	>>I / Preset+	CH/Tracking+	CH+ / Page+
Count Reset	Picture / Format	-/MFT-	Vol-
Count Stop	Zoom / Size	Display On/Off	Display / Media
Clock Counter	Sleep / Timer	CH/Tracking-	CH- / Page-
Tv/VCR	TV/Radio /	1	1
OTR	Setup / OPT /	2	2
PGM Set	Menu / Home	3	3
Index+	Up	4	4
T-Rec	Info / Angle	5	5
Sharpness/V.Hold-	Left	6	6





Original	Sustituto	Original	Sustituto
7	7		
8	8		
9	9		
AFT Retracking	Guide / EPG / -/--		
0	0		
CH Preset	Fav / Marker / PC		
Auto Search	Red / Netflix / Search		
Clock Set	Green / APP / Repeat		
Search Down	Yellow / YouTube / Repeat		
Search Up	Blue / Prime Video / Random		

