



Original	Sustituto
Power	Power
Audio	Audio / Lang I/II
VHS/DVD	Smart / List
1	1
2	2
3	3
CH+	CH+ / Page+
4	4
5	5
6	6
CH-	CH- / Page-
7	7
8	8
9	9
Cancel / Reset	Exit / Cancel / Clear
0	0
-/-- / >=10	Guide / EPG / -/--

Original	Sustituto
Repeat	Green / APP / Repeat
I<< Skip	I<< / Preset-
Skip >>I	>>I / Preset+
REW / << Slow/Search	<< / Tune-
FF / Slow/Search	>> / Tune+
Stop	Stop / Hold
Pause / Slow	Pause / Step / Freeze
Play	Play / Slow
Direct Navigator / Top Menu	D.Menu / Top
Up	Up
Play List / Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Display	Display / Media
Down	Down
Exit / Return	Back / Return





Original	Sustituto	Original	Sustituto
	AV		AV / Input / RDS
	P.Memory		Fav / Marker / PC
	Play Mode		Eject / Surround
	Setup		Setup / OPT /
	Timer		Sleep / Timer
	Music with Picture		Sound / Title
	Rec Check		Rec / Rec Mode
	Group		Vol-
	A / Zoom		Zoom / Size
	B / Quick Replay		Picture / Format
	Dubbing		Subtitle / EQ





Original	Sustituto
VHS/DVD Power	Power
Audio	Audio / Lang I/II
VHS/DVD	Smart / List
1	1
2	2
3	3
CH+ / Tracking/V-Lock+	CH+ / Page+
4	4
5	5
6	6
CH- / Tracking/V-Lock-	CH- / Page-
7	7
8	8
9	9
Input	AV / Input / RDS
Cancel / Reset	Exit / Cancel / Clear
0	0

Original	Sustituto
-/-- / >=10	Guide / EPG / -/--
ShowView	D.Menu / Top
I<< Index	I<< / Preset-
Index >>I	>>I / Preset+
REW	<< / Tune-
FF	>> / Tune+
Stop	Stop / Hold
Pause / Slow	Pause / Step / Freeze
Play	Play / Slow
Prog Play	Text / Goto
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Display	Display / Media
Down	Down










Original	Sustituto	Original	Sustituto
	Exit / Return		Back / Return
	Prog/Check		Shift + TV/Radio / Program
	I-Timer		Shift + Sleep / Timer
	Off Timer		Subtitle / EQ
	Rec Mode		Shift + Rec / Rec Mode
	Timer		Sleep / Timer
	Music with Picture		Sound / Title
	Rec. Check		TV/Radio /
	Rec		Rec / Rec Mode
	Jet Rew		Shift + << /
	A / Ext Link		Red / Netflix / Search
	B / AV Link		Shift + AV / Input / RDS
	Dubbing		Eject / Surround

Original	Sustituto





Original	Sustituto
 Power	 Power
 AV	 AV / Input / RDS
 Volume+	 Vol+
 Volume-	 Vol-
 CH+	 CH+ / Page+
 CH-	 CH- / Page-

Original	Sustituto

