























































Original	Sustituto
	 Power
	 Mute / Dimmer
	 TV/Radio /
	 Setup / OPT /
	 Subtitle / EQ
	 Menu / Home
	 Guide / EPG / -/--
	 Audio / Lang I/II
	 Smart / List
	 Exit / Cancel / Clear
	 Fav / Marker / PC
	 Back / Return
	 Display / Media
	 Info / Angle
	 Vol+
	 Up
	 CH+ / Page+

Original	Sustituto
	 Vol-
	 << / Tune-
	 Left
	 OK
	 Play / Slow
	 Pause / Step / Freeze
	 Right
	 >> / Tune+
	 CH- / Page-
	 Down
	 Stop / Hold
	 Red / Netflix / Search
	 Zoom / Size
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 1





Original		Sustituto		Original		Sustituto	
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				

