
















































| Original      | Sustituto                   | Original   | Sustituto         |
|---------------|-----------------------------|------------|-------------------|
| Guide         | Guide / EPG / -/--          |            | Play              |
| Power         | Power                       |            | Pause             |
| Eject         | Eject / Surround            |            | << / Tune-        |
| Tv/Radio      | TV/Radio /                  |            | >> / Tune+        |
| Red/Goto      | Red / Netflix / Search      | D.Setup    | Setup / OPT /     |
| Green/Angle   | Green / APP / Repeat        | Rec        | Rec / Rec Mode    |
| Yellow/Repeat | Yellow / YouTube / Repeat   | Stop       | Stop / Hold       |
| Blue/A-B      | Blue / Prime Video / Random | I<<        | I<< / Preset-     |
| FAV           | Fav / Marker / PC           | >>I/Index  | >>I / Preset+     |
| Text          | Text / Goto                 | Menu       | Menu / Home       |
| Freeze/Hold   | Shift + Pause / Step /      | Lang/Audio | Audio / Lang I/II |
| D.Menu        | D.Menu / Top                |            | Up                |
| Subtitle      | Subtitle / EQ               |            | Left              |
| Zoom/Size     | Zoom / Size                 |            | OK                |
| Aspect        | Shift + Picture / Format    |            | Right             |
| Subpage       | Info / Angle                |            | Sleep             |
| Media         | Shift + Display / Media     |            | Down              |

| Original | Sustituto             | Original | Sustituto             |
|----------|-----------------------|----------|-----------------------|
|          | Play / Slow           |          | Play / Slow           |
|          | Pause / Step / Freeze |          | Pause / Step / Freeze |
|          | << / Tune-            |          | << / Tune-            |
|          | >> / Tune+            |          | >> / Tune+            |
|          | Setup / OPT /         |          | Setup / OPT /         |
|          | Rec / Rec Mode        |          | Rec / Rec Mode        |
|          | Stop / Hold           |          | Stop / Hold           |
|          | I<< / Preset-         |          | I<< / Preset-         |
|          | >>I / Preset+         |          | >>I / Preset+         |
|          | Menu / Home           |          | Menu / Home           |
|          | Audio / Lang I/II     |          | Audio / Lang I/II     |
|          | Up                    |          | Up                    |
|          | Left                  |          | Left                  |
|          | OK                    |          | OK                    |
|          | Right                 |          | Right                 |
|          | Sleep / Timer         |          | Sleep / Timer         |
|          | Down                  |          | Down                  |





| Original  | Sustituto  |
|---|--|
|    |  Exit / Cancel / Clear  |
|    |  Vol+   |
|    |  Mute / Dimmer  |
|    |  CH+ / Page+  |
|    |  Vol-   |
|    |  Display / Media  |
|    |  CH- / Page-  |
|    |  1  |
|    |  2  |
|   |  3   |
|  |  4  |
|  |  5  |
|  |  6  |
|  |  7  |
|  |  8  |
|  |  9  |
|  |  +  Shift + Guide / EPG / -/-- |

| Original  | Sustituto  |
|---|--|
|  |  0                |
|  |  Back / Return    |
|  |  AV / Input / RDS |
|  |  Picture / Format |
|  |  Sound / Title    |

