



Original	Sustituto
PROGRAM	TV/Radio /
-10	Guide / EPG / -/--
+10	Fav / Marker / PC
Play	Play / Slow
Pause	Pause / Step / Freeze
<<<	<<< / Tune-
I<<<	I<<< / Preset-
>>>	>>> / Tune+
>>>I	>>>I / Preset+
Stop	Stop / Hold
Repeat	Green / APP / Repeat
Vol-	Vol-
Vol+	Vol+

Original	Sustituto

