



| Original | Sustituto |
|---|---------------|
|  | Power |
|  | SD Card |
|  | Input TV |
|  | Input AV |
|  | Menu |
|  | Aspect |
|  | Viera Cast |
|  | Direct TV Rec |
|  | i |
|  | Exit |
|  | Viera Tools |
|  | Viera Link |
|  | Guide |
|  | Up |
|  | Left |
|  | OK |
|  | Right |

| Original | Sustituto |
|---|-------------|
|  | Down |
|  | Option |
|  | Back/Return |
|  | Red |
|  | Green |
|  | Yellow |
|  | Blue |
|  | Text |
|  | STTL |
|  | Index |
|  | Hold |
|  | 1 |
|  | 2 |
|  | 3 |
|  | 4 |
|  | 5 |
|  | 6 |



