






































| Original | Sustituto |
|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/+/10 |  Guide |
|  >/Option |  Options |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Stop |  Stop |
|  Pause |  Pause |

| Original | Sustituto |
|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
|  Slow/Search >> |  >> |
|  << Slow/Search |  << |
|  >>I/Skip Up |  >>I |
|  I<</Skip Down |  I<< |
|  Play DVD/CD |  Play |
|  Play USB |  Red |
|  FM/AM/Ext-In |  TV/R |
|  Top Menu/Direct Navigator |  Shift + Menu |
|  Start |  Blue |
|  Menu/Play List |  Menu |
|  Return |  Back |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  Functions |  Pre Ch |



