






































































Original	Sustituto
	 Power
	 AV
	 TV/R
	 Options
	 D. Menu
	 Red
	 Rec
	 Green
	 <<
	 Yellow
	 Stop
	 Blue
	 Play
	 >>
	 Guide
	 Text
	 Up

Original	Sustituto
	 Down
	 Right
	 Left
	 Ok
	 Menu
	 Vol +
	 Vol -
	 Mute
	 Ch +
	 Ch -
	 1
	 2
	 3
	 4
	 5
	 6
	 7





Original	Sustituto	Original	Sustituto
	Power		Power
	Rec		Rec
	<<		<<
	<<		I<<
	Stop		Stop
	Play		Play
	>>		>>
	>>		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Text		Text
	Menu		Menu
	P +		Ch +
	P -		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	i+		Info
	P < P / -/--		Pre Ch
	Timer		AV
	[?]		D. Menu
	Zoom		Eject
	I / II		Dual

