



| Original | Sustituto | Original | Sustituto |
|---|---------------|---|-----------|
|  | Power |  | Power |
|  | Open/Close |  | Eject |
|  | Home |  | Smart |
|  | Menu/Disc |  | Menu |
|  | Options |  | Options |
|  | Back |  | Back |
|  | Stop |  | Stop |
|  | Play |  | Play |
|  | Pause |  | Pause |
|  | I< |  | I<< |
|  | >I |  | >>I |
|  | >> |  | >> |
|  | << |  | << |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Subtitle |  | Subt |
|  | Goto |  | Guide |
|  | Audio |  | Dual |
|  | [<>] |  | Format |
|  | Volume |  | Media |
|  | Repeat/Repeat |  | Text |

