





































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PC	 Pre Ch
 [i+]	 Info
 [II]	 Options
 [<>]	 3D
 Back	 Back
 Tv/DTV	 TV/R

Original	Sustituto
 Pr+	 Ch +
 Pr-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Source	 AV
 Return	 Shift + Back
 Home	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Exit	 Exit
 EPG	 Guide
 Red/Rec	 Red
 Green/Pause	 Green









































































Original		Sustituto		Original	Sustituto
	Yellow/Stop		Yellow		
	Blue/Play		Blue		
	[...]		Subt		
	[≡?]		Eject		
	[≡i]		List		
	Text		Text		
	HDMI Control		Smart		
	I-II		Dual		
	[> <]		Sleep		
	Size [<>]		Format		
	Input 1		Shift + 1		
	Input 2		Shift + 2		
	Input 3		Shift + 3		
	Input 4		Shift + 4		
	Input 5		Shift + 5		














Original	Sustituto	Original	Sustituto
 Power	 Power	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Enter	 Ok
 4	 4	 Menu	 Menu
 5	 5	 DVD Top	 D. Menu
 6	 6	 Return	 Back
 7	 7	 Play	 Play
 8	 8	 Stop	 Stop
 9	 9	 Pause	 Pause
 0	 0	 >>	 >>
 PC	 Pre Ch	 <<	 <<
 Source	 AV	 >>	 >>
 Mute	 Mute	 <<	 <<
 Vol +	 Vol +	 HDMI Control	 Smart
 Vol -	 Vol -	 Input 1	 Shift + 1
 Up	 Up	 Input 2	 Shift + 2







































































Original		Sustituto		Original		Sustituto	
	Input 3	 + 	Shift + 3				
	Input 4	 + 	Shift + 4				
	Input 5	 + 	Shift + 5				

































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PC		Pre Ch
	[i+]		Info
	Mute		Mute
	Vol +		Vol +
	Vol -		Vol -
	PR+		Ch +
	PR-		Ch -
	Menu		Menu
	Exit		Exit
	DVD Top Menu		D. Menu
	HDMI Control		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Input 1		Shift + 1
	Input 2		Shift + 2
	Input 3		Shift + 3
	Input 4		Shift + 4
	Input 5		Shift + 5





Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PC		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
			Mute
			Mute
			Play
			Play
			Stop
			Stop
			Pause
			Pause
			Rec
			Rec
			>>
			>>
			<<
			<<
			HDMI Control
			Smart
			Input 1
			Shift + 1
			Input 2
			Shift + 2
			Input 3
			Shift + 3
			Input 4
			Shift + 4
			Input 5
			Shift + 5

