







































































Original	Sustituto
 Power	 Power
 Input 1	 Shift + 1
 Input 2	 Shift + 2
 Input 3	 Shift + 3
 Input 4	 Shift + 4
 [ <> ] / [ ≡ ◆ ]	 Picture / Format
 [   >   <   ] / [ ≡ + ]	 Zoom / Size
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 [ i+ ] / Timer	 Sleep / Timer

Original	Sustituto
 0	 0
 P+	 CH+ / Page+
 I-II	 Audio / Lang I/II
 Vol+	 Vol+
 P-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 Return	 Back / Return
 Up	 Up
 Home Menu	 Menu / Home
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat





Original	Sustituto
 Blue	 Blue / Prime Video / Random
 [...]	 Subtitle / EQ
 [≡?]	 Smart / List
 [≡i]	 Info / Angle
 [≡]	 Text / Goto

Original	Sustituto

