



Original	Sustituto
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
FAV	Pre Ch
Recall	Back
Lang	Dual
Time Shift	Smart
Tv/Radio	TV/R

Original	Sustituto
Dev.List	List
EPG	Guide
Subtitle	Subt
Text	Text
Auto	Options
Menu	Menu
Zoom	Eject
Info	Info
Exit	Exit
CH+	Ch +
CH-	Ch -
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
Vol+	Vol +



