






























































Original	Sustituto
	 Power
	 Mute / Dimmer
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 TV/Radio /
	 0
	 Fav / Marker / PC
	 Vol+
	 Setup / OPT /
	 Shift + Smart / List

Original	Sustituto
	 CH+ / Page+
	 Vol-
	 Guide / EPG / -/--
	 CH- / Page-
	 Rec / Rec Mode
	 Smart / List
	 Picture / Format
	 Menu / Home
	 Up
	 AV / Input / RDS
	 Left
	 OK
	 Right
	 Exit / Cancel / Clear
	 Down
	 Display / Media
	 Red / Netflix / Search





Original	Sustituto
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Cyan	Blue / Prime Video / Random
<< / Index	<< / Tune-
>> / TTX	Text / Goto
>> / TTX	>> / Tune+
<< / Sub.Pg	<< / Preset-
>> / Reveal	>> / Preset+
Stop / Hold	Stop / Hold
Play/Pause /	Shift + Exit / Cancel / Clear
Play/Pause /	Play / Slow
Size	Zoom / Size
Subtitle	Subtitle / EQ

Original	Sustituto

