









































| Original | Sustituto |
|---|---|
|  |  Mute / Dimmer |
|  |  Power |
|  |  1 |
|  |  2 |
|  |  3 |
|  |  4 |
|  |  5 |
|  |  6 |
|  |  7 |
|  |  8 |
|  |  9 |
|  |  Guide / EPG / -/- |
|  |  Info / Angle |
|  |  0 |
|  |  Smart / List |
|  |  CH+ / Page+ |
|  |  Up |

| Original | Sustituto |
|---|---|
|  |  Left |
|  |  Vol- |
|  |  OK |
|  |  Vol+ |
|  |  Right |
|  |  Down |
|  |  CH- / Page- |
|  |  Exit / Cancel / Clear |
|  |  Menu / Home |
|  |  Rec / Rec Mode |
|  |  Back / Return |
|  |  Red / Netflix / Search |
|  |  << / Tune- |
|  |  Play / Slow |
|  |  Green / APP / Repeat |
|  |  >> / Tune+ |
|  |  Blue / Prime Video / Random |





| Original | Sustituto | Original | Sustituto |
|--|--|----------|-----------|
|  Blue / >> / Text |  Text / Goto | | |
|  Radio |  Shift + 6 | | |
|  Radio |  Shift + TV/Radio / Program | | |
|  Yellow / Pause |  Pause / Step / Freeze | | |
|  Yellow / Pause |  Yellow / YouTube / Repeat | | |
|  Stop |  Stop / Hold | | |
|  TV |  Shift + 1 | | |
|  TV |  TV/Radio / | | |
|  F1 |  Sound / Title | | |
|  F2 |  Audio / Lang I/II | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Sustituto |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

