



Original	Sustituto
Power	Power
TTX / Mix	Text
TV / DTV	Shift + TV/R
Guide	Guide
CH. List	List
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
APP	Media
Pre-CH / Back	Pre Ch

Original	Sustituto
Pre-CH / Back	Back
Mute	Mute
Vol +	Vol +
Vol -	Vol -
P +	Ch +
P -	Ch -
Source	AV
Menu	Menu
D.Menu	D. Menu
Info	Info
Exit	Exit
Up	Up
Left	Left
Enter / OK	Ok
Right	Right
Down	Down
Red	Red





Original	Sustituto	Original	Sustituto
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Subtitle		Subt
	P.Size		Format
	Sleep		Sleep
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Dual I-II		Dual
	TV / Radio		TV/R
	ALT		Smart
	Text		Shift + Text
	PIP		Options
	Still		Pause
	PIP Swap		3D

