







































































| Original   | Sustituto  |
|--|--|
|  Power  |  Power        |
|  Input  |  AV           |
|  1      |  1            |
|  2      |  2            |
|  3      |  3            |
|  4      |  4            |
|  5      |  5            |
|  6      |  6            |
|  7      |  7            |
|  8      |  8            |
|  9    |  9          |
|  0    |  0          |
|  -/-- |  GUIDE      |
|  S    |  FAV PRE-CH |
|  <<   |  <<         |
|  Stop |  Stop       |
|  Play |  PLAY MODE  |

| Original  | Sustituto   |
|---|---|
|  >>            |  >>              |
|  V.Menu        |  E-MANUAL D.MENU |
|  Mute          |  MUTE            |
|  P+            |  + CH            |
|  P+            |  Up              |
|  P-            |  CH -            |
|  P-            |  Down            |
|  Vol+          |  Right           |
|  Vol+          |  + VOL           |
|  Vol-          |  Left            |
|  Vol-        |  VOL -         |
|  Menu        |  TOP MENU MENU |
|  Display     |  DISPLAY INFO  |
|  P.STD       |  ECO 3D        |
|  Rec         |  REC MODE      |
|  Eject       |  ZOOM          |
|  Pause / P/S |  Pause         |





| Original  |            | Sustituto   |              | Original | Sustituto |
|---|------------|---|--------------|----------|-----------|
|    | Crystal PB |    | TV/R         |          |           |
|    | TRK up     |    | >>I          |          |           |
|    | TRK Down   |    | I<<          |          |           |
|    | Index      |    | List         |          |           |
|    | Memory     |    | Ok           |          |           |
|    | Sleep      |    | Sleep        |          |           |
|    | Lang.Sel   |    | Dual         |          |           |
|    | Clear      |    | Exit         |          |           |
|    | ShowView   |    | Smart        |          |           |
|   | Mix        |   | Shift + Text |          |           |
|  | Text Size  |  | Format       |          |           |
|  | Subpage    |  | Subt         |          |           |
|  | TV/Text    |  | Text         |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |
|   |            |   |              |          |           |

