



Original	Sustituto
	 Blue / Prime Video / Random
	 Sleep / Timer
	 Power
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold
	 Yellow / YouTube / Repeat
	 I<< / Preset-
	 >>I / Preset+
	 Red / Netflix / Search
	 << / Tune-
	 >> / Tune+
	 Green / APP / Repeat
	 Display / Media
	 Exit / Cancel / Clear
	 Shift + Play /
	 Shift + Pause / Step / Freeze

Original	Sustituto
	 Shift + Stop /
	 Smart / List
	 Info / Angle
	 Menu / Home
	 Up
	 Vol+
	 OK
	 Down
	 Vol-

