







































































Original	Sustituto	Original	Sustituto
	Power		Power
	▶▶		3D
	←		Back
	SAT		Smart
	Mute		Mute
	□		TV/R
	[=]		Text
	→ □ / [□]		AV
	□ → / [?]		Shift + AV
	PIP / Split		Options
	PIP to Main		List
	PIP Swap / Split Swap		Pre Ch
	Split Hold		Shift + Pause
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	C		Exit
	[=+]		Shift + Stop
	↑		Up
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow























Original	Sustituto
	Blue
	Info
	D. Menu
	Sleep
	Shift + Format
	Format
	Dual
	Right
	Left
	Menu
	Ok
	Shift + Power
	Shift + Ch +
	Shift + Ch -
	Play

Original	Sustituto
	Stop
	Pause























Original	Sustituto	Original	Sustituto
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 >>	 >>		
 Play	 Play		
 <<	 <<		























Original	Sustituto	Original	Sustituto
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 >>	 >>		
 Play	 Play		
 <<	 <<		





Original	Sustituto	Original	Sustituto
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 <<	 <<		
 Play	 Play		
 >>	 >>		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		

