





























































Original	Sustituto	Original	Sustituto
 Power	 Power	 FAV	 Pre Ch
 Mute	 Mute	 Page+	 Ch +
 1	 1	 Page-	 Ch -
 2	 2	 Up/CH+	 Up
 3	 3	 Down/CH-	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 Red	 Red
 0	 0	 Green	 Green
 Info	 Info	 Yellow	 Yellow
 Recall	 Back	 Blue	 Blue
 Menu	 Menu	 Audio	 Dual
 EPG	 Guide	 Pause	 Pause
 Exit	 Exit	 TTX	 Text

Original	Sustituto	Original	Sustituto
 FAV	 Pre Ch	 TV	 DVD
 Page+	 Ch +	 SAT	 AUX
 Page-	 Ch -	 TV	 DVD
 Up/CH+	 Up	 II	 II
 Down/CH-	 Down	 <<<	 >>>
 Right	 Right	 <<	 >>
 Left	 Left	 LIST	 OPT
 OK	 Ok	 DUAL	 SUBT
 Vol+	 Vol +	 TV/R	 FORMAT
 Vol-	 Vol -	 D.MENU	 AV
 Red	 Red	 MENU	 INFO
 Green	 Green	 OK	 BACK
 Yellow	 Yellow	 EXIT	 HOME
 Blue	 Blue	 SMART	 APP
 Audio	 Dual	 MEDIA	 CH +
 Pause	 Pause	 1	 2
 TTX	 Text	 3	 4



